

Task 1: Install and Configure WSUS

Steps:

- Open Server Manager.
- Click Manage → Add Roles and Features.
- Select Role-based or feature-based installation.
- Choose your server.
- Check Windows Server Update Services (WSUS).
- Select:
 - WID Database
 - WSUS Services
- Specify a content folder
- Click Install.

Post-Installation

- Open Server Manager.
- Click the notification flag.
- Select Launch Post-Installation Tasks.
- Wait until configuration completes.

Task 2: Configure WSUS

- Open Windows Server Update Services.
- Complete the Configuration Wizard.
- Choose:
 - Microsoft Update
 - Synchronize Updates
- Select:
 - Products:
 - Windows 10/11
 - Windows Server
- Classifications:
 - Security Updates
 - Critical Updates
- Start synchronization.

Task 3: Configure Client Machines

Open Group Policy Management.

Create a new GPO named:

- WSUS Policy

Navigate to:

- Computer Configuration
 - PoliciesAdministrative Templates
 - Windows Components
 - Windows Update

Specify intranet Microsoft update service location

Example:

- http://SERVERNAME:8530
- http://192.168.1.10:8530

Apply the same URL for both fields.

Enable:

- Configure Automatic Updates
- Automatic Updates Detection Frequency

Run on each client:

- gpupdate /force

Then:

- usoclient StartScan
- wuauctl /detectnow

Task 4: Approve an Update

In WSUS:

- Updates
 - All Updates

Choose a Security Update.

- Approve

Select

- Install

Task 5: Verify Installation

On client PC:

- Open

- Settings
 - Windows Update
- Install the approved update

Task 6: Generate WSUS Patch Report

- Open
 - WSUS Console
 - Reports
- Generate
 - Update Status Summary
 - Computer Detailed Status Report